

Locket Photo Guide

STEP 1: PRINT YOUR PHOTO

Print your photo at 2x2cm. To ensure it's durable, we always recommend printing on 180gsm-400gsm paper.




STEP 2: PRINT OUR SIZE GUIDE

Ensure your page scale is set to 100% in your printer settings, then print our size guide onto standard A4 paper.

STEP 3: CUT YOUR LOCKET SHAPE

Cut your locket shape and place it on top of your printed photo. Trace the outline then cut around it.




STEP 4: PLACE YOUR PHOTO INSIDE

Open your locket up place your photo inside, ensuring the edges are held safely beneath the small brackets.


MONICA VINADER

Locket Photo Shapes


ID MINI




DEIA & CORDA




ROUND PEBBLE




14K SIREN




HEART




SIGNATURE




DEIA PEBBLE




DEIA TWIST



BIRTHSTONE



ODYSSEY



--- CUT
● PHOTO HOLDER